

Starting up with Chlorine in Hot Tubs

Stain & Scale Preventer is a product that prevents metal & scale buildup. Once the spa is halfway filled, add 1 bottle to the water. Continue filling to the jet line and then run jets for 30 min. Wait a couple hours before adding in the sanitizer. (Note: Remove and clean the cartridge filter within 24 hours.)

- 1) Add ½ oz of Sanitizer Chlorine. (1 Tbsp) Turn the jets on & keep the cover off for 1 hour.
- 2) The next day, add Oxidizing Shock. (2 oz for every 300 Gallons). If using the spa, add it after you get out. Make sure the jets are on & the cover is off for one hour.

(Don't use Chlorine & Shock on the same day or wait at least 12 hours apart.)

- 3) The next day or so, add Calcium Booster. Usually start with 9 oz total, and add in 3 oz increments every 15-20 min.
- 4) Test all levels, or bring in a sample of your water to a Pool and Spa Depot near you. *Make sure you go elbow deep with your bottle, fill it all the way up, and bring it right in for the most accurate results. 2 hours is max for us to give accurate recommendations.*

Note* If you are on "well water", you will need to adjust your alkalinity and pH before beginning the first steps.

Weekly:

- 1) Add 1 Tbsp Sanitizer Chlorine once a week. Turn jets on and keep the cover off for 1 hour. (1 tbsp Sanitizer for every 500 gallons.)
- 2) On a separate day, add Oxidizing Shock (2 oz for every 300 gallons). If using the spa, add it after you get out. Turn jets on and keep the cover off for 1 hour.
- 3) Adjust Alkalinity, pH, and Calcium as needed.