

Sirona: Starting up with Bromine

As you fill the spa, add one bottle of *Sirona™ Prevent*. This is a sequestering agent that will prevent minerals such as calcium, iron, copper and manganese from staining the spa surface or damaging the heater and plumbing. Wait a couple hours before adding in the Sodium Bromide. (Note: Remove and clean the cartridge filter within 24 hours.)

1. Add the Sodium Bromide packet. (½ oz per every 100 gallons.) Then run your jets for a cycle.
2. Add 1-2 Brom Tabs to the filter chamber area. *Make sure the jets are on and the cover is off for one hour.*
3. The next day, or after using the spa, add Activate Granular Shock. (2 oz per every 250 gallons of water). *Make sure jets are on & the cover is off for one hour.*

(Don't use Bromine & Activate Granular on the same day or wait at least 12 hours apart.)

4. The next day or so, add Calcium Booster. Usually start with 9 oz total, and add in 3 oz increments every 15-20 min.
5. Test all levels, or bring in a sample of your water to a Pool and Spa Depot near you. Make sure you go elbow deep with your bottle, fill it all the way up, and bring it right in for the most accurate results. 2 hours is max for us to give the most accurate recommendations.

Note* If you are on "well water", you will need to adjust your alkalinity and pH before beginning the first steps.

Weekly:

1. Add 1-2 Brom Tabs once a week. Turn jets on and keep the cover off for 1 hour.
2. On a separate day, add Activate Granular. If using the spa, add after you get out. Turn jets on and keep the cover off for 1 hour.
3. Adjust Alkalinity, pH, and Calcium as needed.