

Starting up with Sirona: Chlorine

As you fill the spa, add one bottle of *Sirona™ Prevent*. This is a sequestering agent that will prevent minerals such as calcium, iron, copper and manganese from staining the spa surface or damaging the heater and plumbing. Wait a couple hours before adding in the Chlorinating Granules. (Note: Remove and clean the cartridge filter within 24 hours.)

1) Add 1/2 oz of Chlorinating Granules. (1 Tbsp) Turn the jets on & keep the cover off for 1 hour. (1/2 oz or 1 tbsp per 500 gallons once a week- it is important not to overdose the spa with Chlorine)

2) The next day, add Activate Granular Shock. (2 oz for every 250 Gallons). If using the spa, add it after you get out. Make sure the jets are on & the cover is off for one hour.

(Don't use the Chlorine & Shock on the same day or wait at least 12 hours apart.)

3) The next day or so, add Calcium Booster. Usually start with 9 oz total, and add in 3 oz increments every 15-20 min.

4) Test all levels, or bring in a sample of your water to a Pool and Spa Depot near you. Make sure you go elbow deep with your bottle, fill it all the way up, and bring it right in for the most accurate results. 2 hours is max for us to give accurate Recommendations.

Note* If you are on "well water", you will need to adjust your alkalinity and pH before beginning the first steps.

Weekly Maintenance:

1) Add 1 Tbsp Chlorinating Granules once a week. Turn jets on and keep the cover off for 1 hour. (1 tbsp Chlorine for every 500 gallons.)

2) On a separate day, add Activate Granular Shock (2 oz for every 250 gallons). If using the spa, add it after you get out. Turn jets on and keep the cover off for 1 hour.

3) Adjust Alkalinity, pH, and Calcium as needed.